

Note 1: All items need to be completed before notifying Santee Cooper that the site is ready for construction. If the site is not ready when Santee Cooper installation crew arrives, substantial delays in construction completion could result as well as possible remobilization expenses.

Note 2: SC811 requires a 3-day notification to locate underground facilities before any digging can commence. South Carolina State Law requires that excavators give 3 full working days' notice (not including the day of the call) excluding weekends and holidays, for underground facility locators to mark the area.

Note 3: Santee Cooper construction is scheduled by the service area Construction Maintenance Planners. Area Engineering does not schedule construction.

Online Available Customer References :

Meter Installation Specifications Handbook

<https://www.santeecooper.com/pdfs/business/technical-data/handbook.pdf>

Meter Specification Supplemental

<https://www.santeecooper.com/pdfs/business/technical-data/meter-spec-supplement-031609.pdf>

Padmount and Subsurface Equipment

<https://www.santeecooper.com/pdfs/business/technical-data/padmount-and-subsurface-equipment.pdf>

Santee Cooper Service Areas:

- Myrtle Beach - (843) 448-2411
- Berkeley - (843) 761-8000